

## **SURFACE MOUNT**

INSTALLATION (on existing hard surfaced walls)

1. Check to make sure that all contents are included in the box:
  - (1) Glass shelf
  - (2) Mounting brackets
  - (3) Screws
  - (4) Tube-shaped anchors
2. Mark where you would like the corner glass shelf to be installed.
3. Use a level and draw two leveled lines the same length of the shelf, one line for each side of the wall where the shelf will be installed.
4. Determine the center of each line drawn and drill a hole (using a 1/4-in. carbide glass-and-tile bit). Insert the tube-shaped anchor (if installing on an alternate wall type, be sure to select the appropriate anchor) before using the screws provided to hold the mounting bracket in place. Be careful not to damage or dislodge the spacer on the set screw. Set screw should be oriented on the bottom of the mounting bracket after installation.
5. Slide the glass shelf into the mounting brackets, adjusting the set screw at the bottom to ensure a secure fit.

## **RECESSED MOUNT**

INSTALLATION (Recessed Installation, prior to tiling wall or during installation)

1. Determine the height and placement of the corner glass shelving.
2. Tile the wall up to the predetermined location of the shelving.
3. Hold the shelving on the edge of the tile below and determine how much of a groove needs to be cut from the next row of tiles above, to accommodate the height of the shelving. Allow for a 2-3° tilt in the shelf installation to enable better water drainage.
4. Continue tiling the wall leaving the groove required by the shelving utility knife. Leave to dry over night.
5. To secure the shelf in place, use construction adhesive to adhere the shelf into the groove, pressing and holding firmly in place until set.
6. Apply 100% silicon caulking (transparent recommended) around the perimeter of the shelf. Use a wet finger to smooth the bead. Clean up any excess caulk with a damp sponge. Any excess adhesive can be removed carefully with a utility knife. Leave to dry over night.