

Installation Instructions

RECESSED MOUNT

INSTALLATION (Recessed Installation, prior to tiling wall or during installation)

1. Determine the height and placement of the corner marble shelving.
2. Tile the wall up to the predetermined location of the shelving.
3. Hold the shelving on the edge of the tile below and determine how much of a groove needs to be cut from the next row of tiles above, to accommodate the height of the shelving. Allow for a 2-3 degrees tilt in the shelf installation to enable better water drainage.
4. Continue tiling the wall and use a stone cutter, tile cutter or required cutting tool to cut out the grooves required for the shelf. Leave to dry overnight.
5. To secure the shelf in place, use construction adhesive to adhere the shelf into the groove, pressing and holding firmly in place until set.
6. Apply 100% silicon caulking (transparent recommended) around the perimeter of the shelf. Remove excess caulk & adhesive. Leave to dry overnight.