

Installation Instructions

INSTALLATION (Recessed Installation, prior to tiling wall or during installation)

1. Determine the height and placement of the corner marble shelving.
2. Tile the wall up to the predetermined location of the shelving.
3. Hold the shelving on the edge of the tile below and determine how much of a groove needs to be cut from the next row of tiles above, to accommodate the height of the shelving. Allow for a 2-3 degree tilt in the shelf installation to enable better water drainage.
4. Continue tiling the wall leaving the groove required by the shelving utility knife. Leave to dry over night.
5. To secure the shelf in place, use construction adhesive to adhere the shelf into the groove, pressing and holding firmly in place until set.
6. Apply 100% silicon caulking (transparent recommended) around the perimeter of the shelf. Use a wet finger to smooth the bead. Clean up any excess caulk with a damp sponge. Any excess adhesive can be removed carefully with a utility knife. Leave to dry over night.