



Dimension: 1.75"w x 0.44"h



Install the flooring leaving a 1-1/8" gap between the two floors for the reducer installation.



Used to fill the gap between two floors of unequal height or carpet.

Used with floors 7-9mm in height.



Measure and trim to fit.

Center the track between the flooring with 1/4" spacing between the track and floor plank and screw to the subfloor using included screws.

**Surface:** Wear resistant laminate **Core Material:** Moisture resistant MDF



Starting at one end, press the molding into the track inching along the length of the molding. *It will NOT snap in all at once.* You may also use a rubber mallet.