



Dimension: 1.82" w x 0.36" h

# V-T-18

## WATERPROOF T-MOLDING

Used to fill the gap between two floors of equal height.

Used with floors ranging from 6-9mm in height.

**Surface:** Wear resistant  
**Core Material:** Rigid PVC

**1**

Install the flooring leaving a 1-1/8" gap between the two floors for the t-molding installation.

**2**

Measure and trim to fit.

**3**

Center the track between the flooring leaving a 1/4" spacing between the track and floor planks. Screw track to subfloor using included screws (or glue down with construction adhesive).

**4**

Starting at one end, press the molding into the track inching along the length of the molding. It will NOT snap in all at once. You may also use a rubber mallet.