



dimensions®

NON-ACOUSTIC WALL PANEL INSTALLATION INSTRUCTIONS

Basic Guidelines

Installation Environment

- Panels must be installed in a dry, climate-controlled environment.
- Suitable for indoor, residential, or light commercial use.
- Maintain a temperature range of 64°F–86°F (18°C–30°C) and a relative humidity range of 35%–75%.

Owner's Responsibility

- The owner/installer is responsible for the final inspection of the product. Inspect all panels prior to installation for color, finish, and surface quality.
- Do not install any panels that appear damaged or defective. Contact Floor & Decor immediately.
- These installation instructions are intended as general guidelines and do not supersede federal, state, or local building codes. The owner/installer is responsible for ensuring compliance with all applicable regulations, including maintaining safe distances from heat sources such as fireplaces.

Important

- For trimming instructions, scan the barcode located at the bottom of this page.
- Variations in the appearance of natural wood, including grain, texture, and color, are normal and are part of the product's character.
- When installing multiple panels, arrange and blend panels prior to installation to ensure the overall appearance meets your expectations.
- Read the complete installation instructions and warranty information before starting installation.

Installation with Glue and Pneumatic Stapler

Step 1: Prepare the Wall Surface

Before installation, make sure the wall surface is clean, dry, flat, and structurally sound. Installation over drywall, plasterboard, or plywood is recommended. Remove any wallpaper before installing the panels.

Step 2: Apply Adhesive

Apply a construction-grade adhesive to the back of each wall panel in a continuous, even pattern. Follow the adhesive manufacturer's recommendations for application, coverage, and cure time.

Step 3: Fasten the Panels

Panels can be installed horizontally or vertically. Position each panel carefully and fasten along the tongue edge using a pneumatic stapler to help conceal pin marks. Use fasteners appropriate for the substrate and follow the fastener manufacturer's recommendations.

Step 4: Create Outside/Inside Corner Transitions

For corner installations, join the two groove edges together to form a clean 90° corner. Ensure the panels are properly aligned and fully seated before fastening.

Additional Installation Notes

- Before beginning installation, acclimate panels as required by the product-specific installation requirements and confirm that the installation environment meets the conditions above.
- Plan the layout before fastening panels. Dry-fit panels as needed to minimize unnecessary cuts and to create a balanced overall appearance.
- Measure carefully and use appropriate tools for cutting. Wear appropriate eye and respiratory protection when cutting or fastening panels.
- Do not force panels into position. Allow sufficient room for proper alignment and follow the manufacturer's recommended installation pattern.
- Allow construction adhesive to cure according to the adhesive manufacturer's instructions before placing stress on the installation.

Care and Maintenance

Cleaning

- Wipe panels with a dry, soft cloth to remove dust. Avoid abrasive materials, harsh cleaners, or excessive moisture.

Preventing Stains

- If spills occur, immediately blot with a clean, dry cloth to prevent liquid from soaking into or staining the panel.