

MOLDINGS FOR HARDWOOD FLOOR INSTALLATION GUIDE

TRANSITION SOLUTION FOR SIMILAR HEIGHT HARD SURFACE FLOORS



T- Molding is mandatory for use with adjoining similar height surfaces in all doorways less than 48" in length.

Also recommended when making a transition from a wood floor to another floor that is approximately the same height such as ceramic tile. T-Moldings are also used to provide expansion joints when a floor dimension exceeds 40 feet.

When installing T-Moldings, it is important not to obstruct the space for expansion or contraction recommended by the flooring manufacturers. For this reason, you will need a space between the two adjoining floors of approximately 1 1/4 inches to properly install the T-Molding.

Choose the right size: Pennwood Products offers universal T-Molding to fit floors ranging from 1/4 inch in thickness up to 3 /4 inch.



102 Locust Street
P.O. Box 766
East Berlin, PA 17316

Drawn By:
AC

Date Drawn:
03 / 13 /2015

Rev No:
1

Approved By:

Notes: This installation guide covers the installation of hardwood moldings on glue down/nail down flooring installations and floating floor installations.