

Self-Adhesive Wall Panel Installation Guide

IMPORTANT: Self-adhesive strips are very strong, you will NOT be able to peel off and re-apply once adhered to the wall – it is recommended that extra time and care is given as to the placement on the wall prior to adhering to avoid material waste and damage to the wall.

Tools required for installation:

Installing the wall panel requires:

- Level
- Circular saw
- Ladder
- Cloth or dry mop

To achieve a clean cut, saw with finished side facing down when using a circular saw, or facing up with a handsaw or crosscut saw.

Installation:

Panels and joint offset should be a minimum of 12 in. (30 cm) long and 5 in. (125mm) wide. In cases where these minimum dimensions cannot be met, please attach the piece with urethane based adhesive.

Installation of the first row:

- Open the package to let the product acclimate to the room for at least 1 week (7 Days) before the installation. Ensure the surface to be covered with the panel is clean, smooth, firm and leveled by passing over with a dry cloth or mop. Uneven areas must be adjusted.
- Check all panels before and during installation, defective panels should never be installed. Once a defective panel is installed it will be deemed accepted and will not be covered by the warranty.
- **Note:** Do not install panels in bathrooms, shower rooms, or other rooms exposed to excessive moisture. Ensure the indoor temperature is between 59°F-86°F when the panel is installed.
- Remove and fold first quarter of protective membrane on back of panel.
- Place paper protected part of panel to the correct position then stick unprotected part of the panel to the wall. Remove remaining protective paper and stick.
- Continue connecting the panels of the first row until you reach the end of the wall to be covered.
- Cut last panel to fit.

Installation of the second row:

- Begin the next row by cutting some of the length off a new panel to make a joint offset or you can use the remaining piece from the previous row if it is more than 12 in. (30 cm).
- Repeat this process until you reach the last row.

Installation of the last row:

- You may need to cut lengthwise to fit into place. If so, measure and cut the panels accordingly followed by attaching with urethane based adhesive to the back and pressing firmly.

REMINDER: Self-adhesive strips are very strong, you will NOT be able to peel off and re-apply once adhered to the wall – it is recommended that extra time and care is given as to the placement on the wall prior to adhering to avoid material waste and damage to the wall.