

System Includes:



1 - One Quart of DriTac
Repair Adhesive
RS-2



1 - 60cc Plastic
Syringe Assembly
RS-3



2 - Metal Tips
RS-4



2 - Drill Bits
RS-5



Dowels
RS-6



1 - Dowel Punch
RS-7

The Following Items Are Available Separately:



One Quart of DriTac
Repair Adhesive
RS-2



One Gallon of DriTac
Repair Adhesive
RS-8

Everyone Nationwide Is Talking About DriTac's Engineered Wood Floor Repair Kit

"The DriTac Wood Floor Repair Kit is the best product available for repairing hollow spots and loose areas in hardwood floors. This system must have been developed by installers for installers, as it is user-friendly, cost-effective and provides superior results."

Mark Jebo, Hardwood Manager
TOM DUFFY COMPANY, California

"I had a large hollow spot in the floor of my home from another adhesive. I used DriTac's Wood Floor Repair Kit and within 15-20 minutes, the spot was history."

Mike Fritz, Sales Manager
NORTH GEORGIA FLOORING, Georgia

"DriTac's Wood Floor Repair Kit was used on a 2½ foot hollow spot. The homeowner was called the next day and said the repair was perfect. And it took all of twenty minutes!"

Sam LaCour, President
LACOUR'S CARPET WORLD, Louisiana

"DriTac's Wood Floor Repair Kit is a godsend. With the kit, repairs are handled much more efficiently and quickly because there's no cleanup and no need to rip up the boards."

Rob Carney, President
FOXY CARPETS, Florida

"I have used DriTac Wood Floor Repair Kit to repair poorly prepped glue-down hardwood flooring in a commercial environment which is open 7 days a week. This kit enabled me to successfully fix the problem quickly yet allow the business to continue operation without interruption. This enabled me to realize a superior income for a brief jobsite visit and a very satisfied client."

Richard Conway
ALL WOOD FLOORCRAFT, North Carolina

Sika Corporation
1682 Marion-Williamsport Rd E
Marion, OH 43302
+1(740)387-9224
www.DriTac.com

BUILDING TRUST



DriTac

ENGINEERED WOOD FLOOR REPAIR KIT

NOT FOR SOLID WOOD

**PROFESSIONAL GRADE FOR REPAIRING
HOLLOW SPOTS, END-LIFTING AND LOOSE
AREAS FOR MULTI-PLY ENGINEERED
PLANK HARDWOOD FLOORING**

- Cost Effective
- Saves Time & Money
- Compact & Easy to Transport
- Reusable Components
- Cleans Up Easy Wet or Dry



dritac.com
info@dritac.com

BUILDING TRUST



DriTac has developed a repair system to correct the hollow spots and popping conditions for engineered wood flooring installations. These defects cost the flooring industry millions of dollars per year. Studies and experience show that the major cause of problems for engineered wood floor installations are voids between the flooring and the subfloor.

PROBLEMS OCCUR ON JOBS WHERE:

- The flooring adhesive fails to have full contact with the flooring, which results in gaps between the flooring and the subfloor.
- Subfloors are not leveled properly before installation.
- Old adhesives crystalize and release from subfloor due to natural wood movement.
- Wrong spread rate of adhesive, resulting in release of wood from subfloor.
- Warping of wood flooring due to water damage or (out of box) warped product.

BENEFITS OF DRITAC ENGINEERED WOOD FLOOR REPAIR KIT:

- Functional and easy to use for both the professional flooring installer and the “DIYer”.
- Hollow spot or void beneath the flooring is completely filled with the repair adhesive, truly repairing the problem! (Epoxy repair kits only tack down a small section of the problem area).
- Drill bit and applicator tips are much smaller in diameter than conventional repair kits, creating a smaller hole which is easily hidden with putty.
- No need to weigh down the repaired area.
- Cost per repair is a fraction of the cost of epoxy.
- Floor can be walked on immediately after repair. No set up time is required!

INSTRUCTIONS:

- Locate loose area(s) or hollow spot(s) in the wood and outline with blue releasable tape.
- Prepare all hollow areas at the same time. Doing all repairs in a short time period will prevent the syringe from clogging.
- Stir adhesive before using.
- Loading the Syringe: (two options)
 1. Pour directly from bottle into syringe.
 - or
 2. Pour DriTac Repair Adhesive into an open container. Place the applicator tip of syringe into an open container and draw the adhesive up into syringe.

NOTE: Adhesive is thin – It will drip without pressure being applied to the syringe.

- Drill hole(s) with a 3/32” drill bit, (provided in this system), in the area outlined by the blue tape. There may be a need for more than one hole per loose area depending upon size. For larger areas, at least two holes are recommended. Drill one hole at one side of the hollow area and a second hole at the other side.
- Place the applicator tip into the hole and inject adhesive until you feel back pressure. If two holes were drilled, inject adhesive until it comes out the other hole. There may be a need to inject adhesive into the second hole to spread the repair adhesive to the entire area.
- The hollow spot should now be filled in completely. Do not weigh down the repaired area, this allows the adhesive to seek its level.
- Once the void is completely filled use the dowels provided as a plug for the hole(s) drilled. This will keep the adhesive securely under the floor. The dowels are slightly oversized and need to be tapered with a knife or sandpaper to properly fill the hole. Tap the dowel into the hole and cut it off even with the floor. Use the dowel punch provided in this system to lower the dowel below the surface of the flooring.
- Putty the hole with wood filler that blends with the floor color.
- Clean up any adhesive residue with a damp cloth. Dry adhesive can be removed with mineral spirits or safety solvent. Clean out syringe and applicator tip so that it can be reused.

Do not use DriTac Engineered Wood Floor Repair Kit to repair solid wood flooring.

NOTE: This repair system can be used with most glue down engineered wood floors, as long as the adhesive is completely cured. If the original adhesive used for installation was not DriTac, test a sample area for compatibility. Do not use DriTac Engineered Wood Floor Repair Kit to repair solid wood flooring.

CAUTION: If there is a large amount of repair adhesive used to fill a hollow spot, some cupping of the flooring may occur. This cupping will dissipate within several days.

KEEP ADHESIVE FROM FREEZING

Warranty: This product is warranted to be free of manufacturing defects. If a manufacturing defect is found within one year from the date of purchase, such defective product shall be replaced. No warranty either expressed or implied is made regarding the performance of this product since conditions under which these goods are transported, stored, used or applied are beyond our control. This warranty is made in lieu of all other warranties either expressed or implied and the seller shall not be responsible for consequential, incidental, special or other damages no matter what the cause.

SAVING VALUABLE TIME AND MONEY IN 4 EASY STEPS

