



DISCLAIMER

This item presents slight imperfections and shade variations intentionally created during the manufacturing process. These are designed to give the product the depth and richness typically only achieved in artisan hand made products. CHECK ALL PIECES BEFORE INSTALLATION FOR UNDESIREED OR EXTREME VARIATION. NO CLAIMS ARE ACCEPTED AFTER INSTALLATION.

Prep

1. Before starting the installation, inspect all mosaic sheets and make sure the material is in good condition and no defects.
2. To ensure proper adhesion, make sure the wall is flat, smooth, clean and free of dust, dirt, oils, and moisture.

Installation

1. Wear safety items, such as gloves and safety glasses.
 2. Using a ruler and a pencil, trace a line on the tile and cut along the traced line. To ensure proper adhesion, remove excess water from the cut edge of the tile after cutting it. Let the tile dry before sticking it to the wall.
 3. Peel off a small portion of the protective backing and lightly stick into place.
 4. Once tile is in the desired position, apply pressure evenly to the entire surface of the tile making sure to remove the protective backing in the process. Repeat it with the other tiles until you cover the desired area.
- Note: When positioning and placing the peel & stick tile, make sure the tile alignment is correct before applying any pressure. Applying pressure to the tile activates the adhesive, permanently bonding it to the wall. Removing the tiles may cause damage to the substrate.

Recommended tools and materials:

- Safety Glasses
- Gloves
- Utility knife
- Measuring Tape
- Wet saw with diamond blade
- Stone Sealer

TCNA INSTALLATION GUIDELINES SHOULD BE FOLLOWED. READ ALL PACKAGING, DISCLAIMERS AND LIMITATIONS OF THE MATERIAL AND INSTALLATION MATERIAL PRIOR TO STARTING YOUR INSTALL.

SKU# 100604867

Model #:
FD122118005
Description:
PS UPTOWN BRONZE LINEAR MOS

Made in China

EXENCIÓN

Este artículo presenta imperfecciones leves y variaciones de tono creadas intencionalmente durante el proceso de fabricación. Con ello, el diseño le ofrece al producto profundidad e intensidad que generalmente solo se alcanzan con los productos artesanales hechos a mano. ANTES DE LA INSTALACIÓN, VERIFIQUE TODAS LAS PIEZAS PARA VER SI EXISTE VARIACIÓN EXTREMA O NO DESEADA. NO SE ACEPTAN RECLAMOS DESPUÉS DE LA INSTALACIÓN.

Preparar

1. Antes de comenzar la instalación, inspeccione todas las láminas de mosaico y asegúrese de que el material esté en buen estado y sin defectos.
2. Para garantizar una adherencia adecuada, asegúrese de que la pared sea plana, lisa y esté limpia y libre de polvo, suciedad, aceite y humedad.

Instalación

1. Utilice artículos de seguridad, como guantes y gafas de seguridad.
 2. Con una regla y un lápiz, trace una línea en la baldosa y corte por la línea trazada. Para garantizar una adherencia adecuada, retire el exceso de agua del borde cortado de la baldosa después de cortarla. Deje que la baldosa se seque después de adherirla a la pared.
 3. Despegue una pequeña parte del refuerzo de protección y pegue ligeramente en el lugar.
 4. Una vez que la baldosa esté en la posición deseada, aplique presión de manera uniforme en toda la superficie de la baldosa asegurándose de retirar el refuerzo de protección en el proceso. Repítalo con las otras baldosas hasta que cubra el área deseada.
- Nota: al posicionar y colocar la baldosa de despegar y adherir, asegúrese de que la alineación de la baldosa sea correcta antes de aplicar cualquier presión. La aplicación de presión en la baldosa activa el adhesivo, uniéndolo permanentemente a la pared. El retiro de las baldosas puede provocar daños al sustrato.

Herramientas y materiales recomendados:

- Gafas de seguridad
- Guantes
- Cuchillo para uso general
- Cinta métrica
- Sierra para mampostería con hoja de diamante
- Sellador de piedra

SE DEBEN SEGUIR LAS PAUTAS DE INSTALACIÓN DEL TCNA. LEA TODOS LOS EMBALAJES, LAS EXENCIONES Y LAS LIMITACIONES DEL MATERIAL, Y EL MATERIAL DE INSTALACIÓN ANTES DE INICIAR LA INSTALACIÓN.

