

August 30, 2017

Weaber Nickel Gap Shiplap

Installation Instructions

1. Supply List: safety glasses, tape measure, pencil, stud finder, chalk line, level, nails, nail gun, jigsaw, miter saw, wood filler, paint, shiplap
2. If needed, remove all artwork, mouldings, outlet covers and switch plates from your walls.
3. Using a stud finder, mark the location of your studs for nailing guidelines.
4. Using your level, strike a guideline to keep your shiplap level.
5. Beginning at the base of your wall, mark a quarter inch spacer up from your floor. This is where you will begin installation.
6. Place your first board at the quarter inch spacer mark. Insert 2 nails vertically on the face of the board at the stud guidelines until it is secure.
7. Lineup your next board above the first. It will overlap the first board with a 1/4" gap.
8. Remember to make allowances for outlets, windows, and doors. A jigsaw with a guide is recommended for clean edges.
9. Continue installation until your wall is complete.
10. Attach mouldings, fill nail holes, and touch up with paint.
11. Enjoy your new wall finish.

Weaber Lumber

**FLOOR
DECOR** 