

Lizzie 4" Centerset Faucet




Features

- Fits 3 hole sinks
- Push pop-up drain assembly
- Ceramic disc cartridge
- Metal lever handle
- 1.2 gpm (4.5 L/min) max

MODEL# Finish


101137917	Brushed Nickel Finish
101137925	Brushed Gold
101137933	Matte Black

Approvals




Product Diagrams

Front



Side




Please call our toll-free Technical Support line at 877-580-5682 for additional assistance or missing parts.

Lizzie 4" Centerset Faucet



Replacement Parts List



Part	Part #	Description
1	RP13937*	Handle
2	RP70545	Retainer Nut
3	RP64124	Washer
4	RP20080	Ceramic Disc Cartridge - Cold
5	RP20079	Ceramic Disc Cartridge - Hot
6	RP80808	Gasket
7	RP30187	Aerator 1.2 gpm
8	RP56095	Easy install nut
9	RP40269*	Pop-Up Assembly

* Represent for 04:BN / 4408:BG / 7001:MB