

ECOFOREST CORK FLOORING INSTALLATION INSTRUCTIONS

- RECOMMENDATIONS:
- Cork is a natural product. Differences in the structure and shades of planks occur naturally and cannot be oeupted as valid groundsformmpoints.
 - The cork planks should be acclimated by opening the boxes and leaving in the middle of the room in which they ore to be laid for48 hours.
 - Upon opening the boxes, check that all planks ore in the proper condition for installation.
 - Do not install cork floors in humid room spaces such as bathrooms, saunas and laundry rooms.
 - Always leave a gap of approx.imately 3/8" between the edges of the flooring and perimeter walls to allow for possible expansion and movement.
 - lithe room in which the panels ore to be installed hod under floor heating, the surface must not exceed a temperature of 82 degrees. Under floor heating can lead to the formation of crocks in the cork during long heating periods.

- SURFACE PREPARATION:
- Shouldthefloorsurface require leveling, use a quick drying leveling plaster.
 - Cement or cement-derivative floors should be mode impermeable with 0.2 mm moisture barrier in order to protect the panelsfromsub-floormoisture.
 - Cork panels may be laid directly on top of PVC, linoleum, agglomerates or carpets.
 - After laying down the moisture barrier, you can choose to use a cork underlayer in order to improve the sound insulation. When fitting the underlayer, toke care that the joins do not coincide with the joins of the moisture barrier.
 - The Joying of the cork panels is so easy that one almost regrets when the job is finished!
 - You will need a hammer, sow, crowbar or pinch bar with protruding edge and wooden wedges. (Tip: We use a cut piece of thecorkflooroso wooden wedge).

- INSTALLATION:
- IMPORTANT TIPS TO REMEMBER
- Make sure you have acclimated your floor in the room to which you are installing for a minimum of 48 hours.
 - It is advisable to "Shuffle" the boxes (toke a plank from the top of each box and rotate to evenly distribute the natural color).
 - To achieve a clean cut, sow the pattern side down with a jigsaw and up with the hand or cross-cut saw.
 - Check planks and do not install any defective material or they will not be covered on warranty.
 - Because humidity in rooms mn vary, the floor must be able to expand in all directions. The greater the surface area, the greater the room for expansion is required. It must be able to expand and contract on All sides. To facilitate this, an expansion gap should be provided at the room's perimeter and also around any pipes and thresholds. With larger surface areas, a wider gap must be provided. Where possible provide expansion gaps for example under doors. These will be covered by a profile that is not fixed tothecorkfloorbutrotherthe base floor.

- Install the panels, preferably in the same direction as the longest wall. Start installing the floor on one corner or in the middle of the area. You can work from leh to right or right to leh. The easiest way of installing the floor is using the tongue into the groove.
- Position the plank into the previously installed plank at on angle. Move the plank to be fined slightly up and down of the some time exerting forward pressure. The plank will then click into place. In some cases, the planks cannot be rotated into one another, for example, under a door frame, etc. In this case, the planks can also be fined laying flat. IMPORTANT, to do this you need a hammer ond topping block, otherwise you may damage the panels to be fined. Use a number of slight tops until the planks click into place. *Do not try to fit the planks together with one hit.*
- Continue with the rows in this manner. On the final row, there should be on expansion joint of approximately 3/8" between the row and the wall.In doing this, remember you have to sow off the long edges of the final row of planks, to fit. Place these planks one by one next to the planks of the lost row and top the long edges together using the crowbar ond hammer. The shortedgescon be tapped together using a tapping block.
- Aher installation, you can immediately walk on the floor. This is one of the major benefits of cork flooring floor.

- FINISHING:
- Under normal use, no additional finishing is required for your ECOFOREST cork flooring. But in the mse it is deemed necessary to further protect the seams against water infiltration or humidity, another coat of varnish or urethane may be applied to the flooring. Only use a high quality hardwood flooring water-based or oil based polyurethane varnish (see manufacturer's instructions on label for product usage).
 - When the finish begins to show signs of wear, you may dean the floor and apply a new coat.

- CLEANING AND CARING FOR YOUR ECOFOREST CORK FLOORING:
- The type and frequency of maintenance to be applied to ECOFOREST CORK flooring will vary depending on the type and amountoftrafficonthefloor.
- Maintenance and Cleaning:
- Sweep, vacuum or dean with a damp mop or doth on a regular basis.
 - Never pour water directly on the cork floor.
 - Remove liquids and spills immediately.
 - Protect floor covering by using felt protectors on chairs and other pieces of furniture.

On a "need to" basis, it is recommended that the floor be cleaned with a recommended floor cleaning solution. Example: A hardwood cleaner or any neutral floor cleaner (follow manufacturer's recommendation).

Note: Cork is o natural product, thus it is normal to observe minor color shading between panels and slight discoloration from prolonged exposure to sunlight.

ECOFOREST Cork, Inc.WARRANTY
25 Year Limited Residential Wear Warranty
10 Year Limited Commercial Wear Warranty

- ECOFOREST CORK Tiles and Floating Floors are warranted to be free from manufacturing defects. Should a defect occur, ECOFOREST CORK will arrange a credit based on the original purchase of the product.
- WARRANTY COVERAGE
- Upon determination of a valid manufacturing defect, credit will be issued to the dealer and will be good toward the purchase of new ECOFOREST CORK Tile or floating floors. Credit applies to the affected area and do not include lobar.
- These warranties apply in the continental U.S., Alaska, Hawaii, Puerto Rico and Canada. We exclude and will not pay consequential damages under this warranty. By this we mean any loss, expense damage other than to the cork product itself that may result from a defect in the cork product. No implied warranties, including warranties of merchantability and fitness for a particular purpose beyond the term of this wrinen warranty, with the exception of our water damage warranty.
- ECOFOREST CORK limited Residential Weor Warranty does not cover,
1. Problems due to moisture, mildew, alkaline substances or hydrostatic pressure.
 2. Dissatisfaction due to improper maintenance or installation. (See ECOFOREST CORK Installation Guidelines).
 3. Damage due to scratches, gouges, scuffs, punctures, cuts, indentations, burns, accidents, lack of proper furniture rests or any intentional misuse of the products.
 4. Color variation between samples and/or illustrations of the actual product.
 5. Noncompliance with installations and/or usage as recommended by ECOFOREST CORK.
 6. Cracking, warping, soiling, fading, improper maintenance or abuse by items such as roller skates, golf shoes or pets.
 7. Floor covering installed on stairs or other inappropriate locations is excluded from the warranty.

ECOFOREST CORK INSTRUCCIONES DE INSTALACION DE PISO

- RECOMENDACIONES:
- Corcho es un producto natural. Diferencias en la estruduro y motiz de los tobias ocuren naturolmente y nose puede aceptorcomorozonesvalidos para las quejos.
 - Los tobias de corcho se deben odimotizorse obtriindo las cajas y dejondolos en el media de la hobitod6n donde seran instalodospor48 horas.
 - Al abrir las cajas, verificar que todos los tobias esten en condici6n propio para instalaci6n.
 - Nose puede instolor el piso de corcho en hobitaci6nes humedos como el bafio, saunas y cuarto de lavandera.
 - Siempre dejar un espod6 oproximado de 3/8" entre el fila del piso y el perimetro de la pored para permitir movimientoyexposici6npossible.
 - Si la hobitoci6n dondelostoblosseron instalodostiene un colentodordepiso, lo superficie nopuedeexcederuno temperatura de 82 grodos. Colentadores de piso pueden lograr formoci6n de roturos en el corcho durante largo periodosdecoliente.

- PREPARACION DEL SUPERFICIE:
- De requerirmivelarlosuperficedel piso, use un nivelodoremplastadodesecoligero.
 - los pisos del cementa o del cemento-derivado se deben hacer impermeobles con la borrero de humedad de 0.2mm poro protegerlospanelescontralahumedaddelosuperficie.
 - Tobias de corcho se pueden ser instalados direcio encima de alfombras, PVC, linoleo o oglomeros.
 - Despues de instolor la borrero de humedad, se puede escojer usar un refuerzo de corcho par mejorar el oislamiento de sonido. Al ojustor el refuerzo, estar pendiente que las uniones no coinciden con los uniones de la barrera de humedad.
 - La colocaci6n de las tablas de corcho estan focifque uno casi/omenta cuondo el trobojo se acaba.
 - Usted necesitorio un mortillo, sierra, palanca o palo nco con dientes y un trozo de madera (Consejo: Nosotros utilizamos un pedazodelpisodecorchocomeeltrozodemadera).

- INSTALACION:
- AVISO5 IMPORTANTES PARA ACORDARSE
- Asegurese de aclimatar el piso en la hobitaci6n en donde sera instalada por lo menos 48 horas antes.
 - Es prudente de mexclar las cojas (escoger una tabla de encimo de coda caja y rotor para distribuir iguolmente el color natural).
 - Para alcan1or un corte limpio corte con el diseno boca abajo con un rompecobelas y hacia arriba con uno sierra de mono o sierra de cru1cortado.
 - Examinar las tobias y no instale ningun material que este defectuoso o la garantia no los cubrira.
 - Porque la humedad en cuartos puede variar, el piso debe poder ompliorse en todas las direcciones. Entre mas grande la greo superficial, mayor vo ser la expansi6n requerido en el cuarto. Debe poder ampliarse y contraer en TODOS LOS ladas. Para facilitar esto, un boquete de expansi6n se debe proporcionar en el perimetro del cuarto y tambfin alrededor decuolquierpipoyumbralquepuedohober.Conlosgreosuperficialesm6grande,unboquetem6sampliodebeser proporcionado. Donde sea posible proporcione los boquetes de la expansi6n, par ejemplo debajo de puertas. Estos ser6n cubiertos por un perfil que no este fijado al piso del corcho sino a la bosa del piso.

- Instole los poneles, preferiblemente en la misma direcci6n que la pored mas largo. Comience a instalar el piso en uno esquinooen elcentrodel6rea. Usted puedetrabojordeizquierda oderecha odederecho a izquierdo.lo monero mas f6cildeinstalarelpisoesutilizandolalengUetaenelsurco.
- Coloqueel ponelconel anterior a un6ngulo. Muevoel ponelquesto instalondo levementehocioarribayhocioabajo al mismo tiempo que ejerce la presi6n delontero. El panel entonces choscaro en lugar. En algunos casas, no podr6 rotor el panel con otro, par ejemplo, bajo el marco de uno puerto., etc. En este caso, los paneles podr6n ser colocodos ocostodos. IMPORTANTE, para hacer esto usted necesito un mortillo y un bloque que golpeo ligeramente, sino usted puede dofi6r los paneles que este colocondo. U6ilice un n6mero de golpecios leves haslo que los poneles hogan conexi6n. *No intente conodor los pane/es juntos de un solo golpe.*
- Continue con los filas de este modo. En la fila final, debe haber uno junto de dilotoci6n de aproximodamente 3/8" entre la fila ylo pared. En haceresto, recuerdede usarlo sierra paracortorlosbordeslargosde lafilofinal deponeles, para caber. Coloque estos paneles uno par uno allado de los poneles de la fila anterior y golpee ligeramente los hordes largos juntos con uno poloncaomortillo.
- Desp6s de la instalaci6n, usted puede cominor inmediotamente en el piso. Este es una de las ventajas principales de los pisosdeflotoci6n delcorcho.

- TERMINACION DEL PISO:
- Bojo uso normal, nose requiere ninguna terminoci6n odicional para su piso de corcho de ECOFOREST. Pero en caso que se determine necesorio de proteger el piso odici6nolmente contra la filtraci6n de ogua y la humedad, otra mono de borniz o urethane puede ser aplicado al piso. Solo uso borniz en alto colidad para madera dura con uno bosa de oguo o oceite {ver lasinstruci6nes en loetiquetodel fabricconteporo el uso del producto}.
 - Cuondo el pulido del piso tenga se6ales de uso, puedes limpiar el piso y dorle uno mono nueva de bamiz.

- CUIDANDO Y LIMPIANDO SU PISO DE CORCHO DE ECOFOREST:
- El tipo y frecuencia de mantenimiento hacerse oplicado al piso de corcho de ECOFOREST varia dependiendo en el tipo y mntidaddetrafficoenelpiso.
- Mantenimiento Y Limpieza:
- Borrer, usar opirodoro electrica o limpiar con un mapa o pafio humedo con regularidad.
 - Nunco hechoroguo directoal pisodecorcho.
 - Remover liquidos y derrames inmediatamente.
 - Protejerel pisocubriendo lossillosyotrosmueblescon protectoresde lana.

Por si fuese necesario, se recomiendo que el piso se limpie con una soluci6n remmendado para limpiar piso. Ejemplo: limpiador de piso de madera o un limpiador neutral de piso (seguir los remmendoci6nes del fabricante).

Nota: Corcho es un producto natural, es totalmente normal observar varioci6n en el color entre paneles y uno pequefia discoloraci6n porelponerse a losroyosdelsol.

GARANTIA ECOFOREST Cork, Inc.
25 aios garantio limitada de uso residencial
10 aios garantio limitada de uso comercial

- ECOFOREST CORK losetos y piso de floto son garantizados de ser libre de defectos del fabricante. De ocurrir un defecto, ECOFOREST Cork horo los arreglos para un credito establecido en la com pro original del producto.
- CUBIERTA DE LA GARANTIA
- De determinar que hoy un defecto valido del fabricante, un credito sera emitido al comerciante y sera buena hacia uno com pro nuevo de ECOFOREST CORK losetos y piso de floto. El credito es oplicable a la area olectada y no incluye labor.
- Estas garantio aplican en el continente de US, Alaska, Hawaii, Puerto Rico y Canada. Nosotros excluimos y nose pagoro dofios consecutivos bojo esto garantio. Quiere decir alguno perdido, gasto de dafios que sean del producto de corcho de el mismo que resulte de un defecto en el producto de corcho. No gorontio incluido, incluyendo garantio del negociante y propiedad para unpropositoporticulorlomosollodelterminodeestogarantiaescrito, con lo excepci6ndenustragorantiadedafiosdeaguo.
- ECOFOREST CORK garantio de uso residenci6llimitada no cubre lo siguiente:
1. Problemas par humedad, moho, sustancias de alcolino y presi6n hidrost6tico.
 2. Disgusto par instoloci6n o mantenimiento impropio.(Ver los guios de Instaloci6n de ECOFOREST CORK).
 3. Dafios par royosos, gubia, marcos de zopotos, picodo, corturas, dentor, quemoduro, occidentes, folio de descansos apropiadosporlosmueblesomaltrotointend6ndelproducto.
 4. Varioci6n de color entre la muestra y/o la ilustraci6n y el producto actual.
 5. Folta de cumplimiento con instolaci6n y/o el uso recomendado por ECOFOREST CORK.
 6. Rojadura, desviemento, ensucioemento, decodencia, mantenimiento impropio, abuso par orticulos como mascotas, zapotos de golly patines.
 7. Pisosinstaladosenescalerosubicaci6nesimpropiossieron excluidosdelogarantio.