

ENGINEERED CLICK INSTALLATION INSTRUCTIONS

3/8", 7/16", 1/2", 5/8"

Float-In / Glue-Down

Important / Read First

Please read and review installation instructions completely before proceeding with the installation. We recommend the installer follow all guidelines set forth by the National Wood Flooring Association (www.nwfa.org) for job site, subfloor and general installation recommendations.

Engineered hardwood flooring can be installed on all grade levels; on grade, above grade and below grade. This includes installation directly to concrete, terrazzo and wood sub floors, or over existing ceramic tile, wood and vinyl floors, with proper preparation.

Installer/Owner Responsibility

It is the responsibility of the owner/installer to inspect the flooring. It is also the owner/installer's responsibility to ensure the jobsite conditions, plus the jobsite sub floors are environmentally and structurally acceptable prior to the beginning of installation.

Prior to installation, the owner and or installer are responsible for the final inspection of materials and is encouraged to report any deficiencies in grade, manufacture and finish directly to the seller. Should an individual piece be questionable or not meet standards, it should not be used. Materials installed with visible defects will not be covered by the warranty.

The owner and/or installer are responsible for ensuring that the proper installation conditions and appropriate sub floors meet or exceed all NWFA industry standards. Proper installation can be affected by adverse moisture content in the product, humidity at the job site, acclimation of flooring to local site conditions, preparation of job site, preparation of sub floor, and flooring layout. The sub floor must be clean, flat, dry and structurally sound.

We recommend ordering 5% above the actual square footage requirements to allow for cutting and grading of material.

Due to inherent variations with wood flooring product the installer must work out 4-5 cartons simultaneously to ensure proper blending across the floor.

Proper Site Conditions & Handling

1. The building must be complete & enclosed. It is essential that masonry, dry wall, paint and all other 'wet' work to be completed, given time to thoroughly dry as this will affect the moisture content of the job site.
2. The exterior grading should be complete with all gutters, downspouts and drainage directed away from the building. The crawl space must have adequate cross ventilation (equaling 1.5% of the, on grade, total sq ft) and a vapor barrier of 6-8 mil polyethylene film (covering 100% of the crawl space), joints overlapped and taped. There must also be a minimum of 24" from the ground to the underside of the joists.
3. Permanent HVAC systems must be working and in operation 7 days prior to installation to stabilize the interior environment at normal living conditions and to acclimate the flooring. The HVAC must also be

in operation during and after the installation to ensure a stable environment to protect the hardwood floor. Ideal conditions are a temperature between 60-80 degrees Fahrenheit (15-26 degrees Celsius) and relative humidity between 35-60% at all times during and after installation. The use of a humidifier or dehumidifier may be required to maintain these conditions.

4. Engineered wood flooring can be installed on, below and or above grade level, but should not be installed in full bathrooms or other wet environments.

5. Take special care when transporting & unloading hardwood flooring at the job site. Store the hardwood flooring in a safe dry place making sure to provide a 4" air space under cartons that are stored upon "on-grade" concrete floors. Flooring should be stored in small lots in the rooms where the installation will take place and allowed to properly acclimate/condition to the job environment.

6. Flooring should be allowed to acclimate for a minimum of 72 hours or longer until conditions are at normal living conditions and meet minimum installation requirements for moisture content.

7. Moisture content should be checked with the appropriate device to ensure proper installation conditions. Moisture content of wood sub floor should not exceed 11% and the moisture content of the wood should be within 2% of the sub floor.

8. Concrete sub floors must be fully cured for a minimum of 60 days and dry (3lbs or less/24 hrs/1,000 sq. ft., with a calcium chloride test) or less than 75% with relative humidity probes (in-situ testing)

9. Ensure exterior landscaping is complete and graded away from the foundation. Gutters and downspouts must be in place directing rain water away. Always store wood flooring in a controlled environment of 60 - 80° Fahrenheit (15° - 26° Celsius) and 35% - 60% relative humidity.

Sub Floor Types & Requirements

Preferred Plywood Sub Floor: Use 4'x 8' sheets of 5/8 CDX grade Plywood underlayment or 23/32" OSB underlayment with joist spacing 16" on center or 19.2 on with floor truss system. If joists are spaced over 16" on center or floor truss system over 19.2" on center, an additional layer of 1/2" CDX laid diagonal or perpendicular with 1/8" spacing will be required between sheets of underlay. Particle board is not an approved subfloor for nail down or glue down applications.

Minimum Plywood Sub flooring Requirements: 4' x 8" sheets of 5/8" CDX grade underlayment with a maximum 16" on center joist construction. If joist system is spaced over 16" on center an additional layer of 1/2" CDX Plywood underlayment, laid diagonal or perpendicular, will be required.

* Minimum specified materials at maximum span and spacing may result in movement, gaps, and noises.

Solid Board Sub flooring: Should be 3/4"x 5 1/2" Group 1 dense softwoods, No.2 Common, Kiln dried less than 15% MC.

Concrete: Engineered Hardwood Floors can be laid on concrete provided an appropriate sub floor and moisture barriers are installed over concrete.

1. Make sure concrete is flat, dry, structurally sound and clean.
2. Floor should be flat to within 1/4" in 10' or 1/8" in 6'.
3. Substrate should be flattened to tolerance.
4. Always use a 6 mil poly moisture barrier when installing over concrete (Floating installation).

5. If a concrete sub floor is lightweight (less than 100 lb) rule of thumb: Draw a nail across the top of concrete and if it leaves an indentation, it is probably lightweight concrete and cannot be installed using the glue down method. With light weight concrete you must float the wood flooring.

Moisture testing for material and wood subfloors:

Using a pin-style meter, test wood for moisture content. Wood should be between 6% - 9% moisture content prior to installation. The subfloor should be within 2% difference of the hardwood, with the moisture content of the subfloor not to exceed 11%.

Crawl spaces must be cross-ventilated (1.5% of the total sq. ft.). 6-8 mil black poly covering 100% of the ground and a minimum of 24" from the ground to the bottom of the joists.

Test concrete for moisture using one of the following methods:

Calcium chloride test: Follow test manufacturer's directions, performing 3 tests for the first 1,000 s/f and one additional test for every subsequent 1,000 s/f. Moisture emission rate should not exceed 3 lbs per 1,000 s/f.

Insitu test: Relative humidity probes should read 75% relative humidity or less in all areas.

For further information on moisture testing, follow the guidelines published by the National Wood Flooring Association, www.nwfa.org.

Additional Sub Floor Notes

Sub floor surface must be clean, level, structurally sound, and dry. Manufacturer will not be responsible for any product failure due to poor sub floor conditions or materials. Unsound or damaged sections should be repaired or replaced.

Sub floor surface should be scraped or sanded clean and made flat prior to installation. The surface must also be free of any wax, dirt, paint, oil, grease, sealers, curing compounds and other debris. Sand or grind high spots and fill low spots with an approved floor patch compound.

It is very important to nail or screw any area of loose or moving sub floor that will cause squeaks. Manufacturer recommends the use of nails or screws with panels fastened every 12 inches along the joists or intermediate supports to ensure soundness of floor when complete.

Sub Floor Inspection and Room Preparation

Sub floor must be completely dry. If installing over new concrete slab, allow 60 days or more to dry thoroughly. The installer must test the concrete using recommended testing methods and levels.

Sub floor must be free of any paint, oil, greases, dirt, sealers, curing agents, dust and other residues.

If installing on any wood sub floor, the moisture content difference between engineered wood floor and wood sub flooring should not be more than 2%.

If installing over existing vinyl floor, make sure vinyl is free of waxes, polishes, and is secured to the sub floor and that the underlying sub floor meets sub floor conditions.

Screw down all creaking and loose sub flooring.

Remove doors and existing baseboards, quarter rounds and thresholds.

Door frames and other wooden obstacles should be sawed off at the bottom to allow enough room for the underlayment and planks to slide under.

General Installation Requirements

All wet trades such as tiling, drywall, painting etc. must be completed before hardwood is installed or delivered to the site.

1. Evaluate job-site and sub floor condition to ensure proper installation environment.

2. Read the product instructions thoroughly.

3. The completed floor is only as good as the sub floor, and the installer.

4. Allow for an expansion space of 1/2" around all vertical obstructions.

5. Should a piece be doubtful due to manufacturing, color, finishing, grade or having a visual defect, do not install it. Cut it for the wall line or place it in a closet. Work out of multiple cartons for a random appearance.

Note: Engineered may only be installed over hydronic radiant heat (not to exceed 85 degrees Fahrenheit at the subfloor) and in compliance with NWFA guidelines. Please refer to www.nwfa.org/

Never strike the floor with a hammer or mallet as this may damage the finish. In glue down and floating applications, do not use ratchet straps or tape to secure the floor.

For glue down or floating applications, restrict any foot traffic for 12 hours following installation.

Note: Minor occasional noise (such as squeaking) within the flooring is inherent to all installation hardwood flooring applications and can occur as environmental conditions change.

Completing the Job

1. Fill visible joints and gaps with a non-silicon based filler that blends with the floor color. Helpful hint: Test filler on spare piece of plank.

Note: The use of fillers/putty and stain is a recommended and acceptable industry practice. Full plank replacements are also acceptable forms of repair and do not affect the integrity of the floor when done correctly

2. Install molding and trim making sure not to nail into the hardwood flooring.

3. Sweep and/or vacuum floor then clean with a hardwood flooring cleaner.

Note: You must stay off floor for at least 12 hours when using either floating or glue down methods.

Upon completion, cover the floor with a breathable wrapping to protect the finish if necessary.

Asbestos Warning

Do not sand existing resilient tile, sheet flooring, backing, or felt linings as these products may contain asbestos fibers that are not easily identified. The inhalation of asbestos dust can cause asbestosis or other serious bodily harm. Check with local, state, and federal laws for handling hazardous material prior to attempting the removal of these floors.

Wood Dust

Sawing, sanding and/or machining wood products can produce wood dust, which can cause a flammable or explosive hazard. Wood dust may also lead to lung, upper respiratory tract, eye, and or skin irritation, and some species of wood may cause dermatitis and or allergic respiratory effects. The International Agency for Research on Cancer (IARC) has classified wood dust as a nasal carcinogen in humans. The National Toxicology Program (NTP) has also classified wood dust as a known human carcinogen.

- Avoid dust contact with ignition source.
- Sweep or vacuum dust for recovery or disposal.
- Avoid prolonged or repeated breathing wood dust in air.
- Approved respirators may be needed depending upon dust conditions.
- Avoid dust contact with eyes and skin. Wear Gloves and safety glasses when handling and machining the product.
- First Aid: If inhaled, remove to fresh air. If irritation persists, contact a physician.

Tools & Accessories

Broom/Vacuum	Saws and jamb saw Hammer
Ear Plugs and Glasses	Pencil
Vapor Retarder	Tapping Block
Underlayment	Rubber Mallet
Tape Measure	Hard Wood Cleaner
Dust Mask	Chalk line
Proper Trowel	Moisture Meter (wood & concrete)
Galvanized finish nails	
Titebond® or other Floating wood or laminate floor specified tongue and groove adhesive for float-in installation	
Moisture-Cure Urethane adhesive for direct-glue installation.	

Floating Installation

Note: Tongue and groove adhesive must be used on all end joints when utilizing the floating installation method.

1. Determine starting wall and direction to lay boards. An outside wall is normally best as it is most likely straight and square with the room. In cases of suspended wood sub floors, wood should be installed perpendicular to the joists. In cases of existing wooden floor, boards should be laid crosswise or at a 45 degree angle.
2. Lay underlayment in same direction as boards using a combination of polyethylene and foam underlayment or a 2 in 1 combined product making sure to tape the seams and overlap the poly edges by 4" (do not overlap the actual foam pad). The vapor barrier must be continuous without cuts or punctures. Tape any tears, cuts and seams.
3. Begin installation by laying first row of boards, tongue side facing the wall. Remove tongue prior to installation.

4. Maintain expansion gap of 1/2" between first board and the wall by using spacers regularly along the length of the wall. Determine straightness of wall by snapping a chalk line. If starting wall is not straight, make notation on first row and saw to shape.

5. Begin installing the click flooring. Ensure a tapping block is used to assemble, never tap boards together using only a hammer or mallet.

6. Apply 1/8" bead of tongue and groove adhesive to bottom of groove on all end joints during assembly. Failure to apply adhesive may result in excess squeaking.

7. Using a tapping block (if needed), tap the joints together. Do not hit floor board directly with hammer or mallet. If needed, use a pry bar or pull bar at ends to pull boards tight (do not use ratchet straps or tape).

8. Continue process across the room. The last board should be sawn to appropriate width allowing for 1/2" expansion space against walls and all vertical obstructions.

9. Stagger end joints (at least 6") and randomly install different lengths to ensure natural appearance. Do not create discernible patterns such as "H" or "steps". Select boards to create a uniform appearance without clusters of short lengths or sections of light or dark planks. Do not install any objectionable boards that have visual defects or are not consistent with the grade being installed.

10. The end joint must be at least 6" from the end joint in the row before it. A minimum of one end joint is required in every row, regardless of width (e.g. hallways).

11. Do not install floating floors in excess of 30 feet without the use of transitions

12. Use transitions at doorways and other adjacent floors.

13. Do not affix the floor to the subfloor at any point.

Glue-Down Installation

1. Determine starting wall and direction to lay boards. An outside wall is normally best as it is most likely straight and square with the room. Wood should be installed perpendicular to the joists. In cases of existing wooden floor, boards should be laid crosswise or at a 45 degree angle.

2. Begin installing the first row in the left corner of the base wall when facing the wall. Remove the tongue from the long and short sides of the first board. Install the first board against the ½" expansion shims to your left and the long length of the board is against the ½" expansion shims in front of you.

3. Maintain expansion gap of 1/2" between first board and the wall by using spacers regularly along the length of the wall. Determine straightness of wall by snapping a chalk line. If starting wall is not straight, make notation on first row and saw to shape.

4. Remove the tongue from the long side of the second board connect the end of the second board to the end of the first board, making sure the boards are tightly connected and firmly positioned against the shims. Use the hammer/rubber mallet and tapping block to tap the tongue end of the second board to ensure a tight fit. **Never use the hammer or rubber mallet directly on the flooring as this will cause damage to the board.**

5. Continue placing additional boards moving left to right using the same procedure until the first row is complete.

6. You will need to cut off the end of the final board, save the remaining piece for the next row as long as it is at least 6" long. Use the last board Puller to ensure the last board is tight against the preceding board. Place shims between the end of the last board and the wall. Use the shims to wedge the row in tight rendering it immobile.

7. Once the first row has been cut and fit, remove the flooring and set it aside. Snap a chalk line the face width of the wood flooring plus 1/2" for expansion space out from the starting wall. Starting from the edge of the chalk line, apply an even layer of adhesive as instructed by the adhesive manufacturer. Only spread adhesive the width and length of the one row that was dry fit.

A NOTE ON ADHESIVE:

Follow the adhesive manufacturer's instructions for use in this application. Wear rubber gloves and proceed carefully during adhesive application. Cured mastic is very hard and sometimes impossible to remove from the flooring as well as the tools. **DO NOT** allow any spilled or excess adhesive to remain anywhere but between the boards and the subfloor at any time during the installation. Clean up spills immediately as recommended by the adhesive manufacturer. **The flooring manufacturer will not be responsible in any way for adhesive that is not removed from the hardwood flooring immediately. Any damage to the flooring caused by the adhesive allowing to cure on the surface will be the sole responsibility of the installation mechanic.**

8. Re-install the pre-cut boards from the dry fit as follows. Connect the end of the second board to the end of the first board, making sure the boards are tightly connected and firmly positioned. Use the hammer/rubber mallet and tapping block to tap the tongue end of the second board to ensure a tight fit. **Never use the hammer or rubber mallet directly on the flooring as this will cause damage to the board.**

9. Continue placing additional boards moving left to right using the same procedure until the first row is complete.

10. Place shims between the end of the last board and the wall. Use the shims to wedge the row in tight rendering it immobile.

11. Start each new row on the left side with the remaining portion of the previous row as long as it is at least 6" long; otherwise cut a new starter board. Stagger end joints (at least 6") and randomly install different lengths to ensure natural appearance. Do not create discernible patterns such as "H" or "steps". Select boards to create a uniform appearance without clusters of short lengths or sections of light or dark planks. Do not install any objectionable boards that have visual defects or are not consistent with the grade being installed.

12. The end joint must be at least 6" from the end joint in the row before it. A minimum of one end joint is required in every row, regardless of width (e.g. hallways).

13. Trowel adhesive onto the subfloor as recommended by the adhesive manufacturer, place the next board in position with the groove edge of the board along the chalk line leaving 1/2" expansion space against the wall. Before you finish tapping the board onto the previous row, you must be sure the end joint is tight. If the end joint is not completely tight you will not be able to do so once the long seam is tight.

14. Continue process across the room. The last board should be sawn to appropriate width allowing for 1/2" expansion space against walls and

all vertical obstructions. The last board puller will be used to install the last row.