

35 YEAR LIMITED WARRANTY PROGRAM

ENGINEERED PREFINISHED HARDWOOD FLOORING

The limited warranties below apply only to pre-finished products and are effective with purchases made after June 19th, 2024. All warranties are limited to the original purchaser only. Retain your original sales receipt or customer agreement and all initial test documentation (temperature, relative humidity, sub-floor moisture, etc.).

RESIDENTIAL FINISH WARRANTY

Residential Flooring Manufacturer warrants that the finish will not wear through to the wood within **35 years or** as long as the original purchaser owns the floor, whichever is less. Gloss reduction is not considered wear through and is not covered by the warranty. **EXCLUSIONS AND LIMITATIONS DO APPLY. SEE BELOW FOR DETAILS.**

MATERIAL WARRANTY

Flooring Manufacturer warrants that the products have been manufactured in compliance with the grading rules of flooring manufacturer, and will be free from manufacturing defects for as long as the original purchaser owns the floor. Manufacturing defects do not include natural wood characteristics such as mineral streaks, knots, grain variations, worm holes, normal minor differences between color of samples, photos, the color of installed floors, color variations from board to board, or differences between moldings and flooring. Use of putty or stain pens during installation is considered normal. Minor width variation is to be expected and is not considered a defect. Claimed defects should be visible from a normal standing inspection position and not require reflective or special lighting to detect.

EXCLUSIONS AND LIMITATIONS

No warranty coverage is provided for flooring that contains obvious defects of any kind that were installed nonetheless. If, before installation, you discover any flooring that has obvious defects, please immediately contact the dealer from whom the flooring was purchased and replacement flooring will be provided at no cost.

These warranties do not cover damage, indentations, scratches, or stains arising from negligence, accidents, abuse, fire or excessive heat, abnormal wear, construction, spike heels, grit, sand or other abrasives, dents, insect infestation after the product has left our factory, domestic animals or tape applied to the floor's surface. Splits and cracks after installation are normally caused by improper home environment rather than manufacturing.

It is critical that all installations are done in compliance with the procedures outlined in the flooring manufacturer's installation instructions, which can be found in each carton of flooring. No damage or defects caused by improper installation or failure to provide a suitable installation environment (including proper acclimation) are covered by this warranty. Failure to install your flooring in accordance with the instructions will void all warranties.

These warranties do not cover damage caused by use of the flooring for purposes other than those for which it was designed; damage caused by disasters such as fire, flood, wind, and lightning; damage during shipment; or any other abuse or misuse by the purchaser.

The flooring should only be cleaned using a good quality cleaner (such as Bona Hardwood Floor Cleaner) made specifically for wood flooring. Remove any loose dirt or grit from the floor. The cleaner should not be liberally applied to the flooring, only misted via the floor care system selected if automated or applied directly to the micro-fiber pad. Use of non-approved cleaning and maintenance products including oil soap, liquid/paste wax, oil, silicone or ammonia based products will void all warranties. Do not wet mop or use steam cleaners of any kind on the floor.

After your floor is installed, it is critical to maintain a normal temperature between 60°-80° F and a relative humidity between 35-55%. Failure to follow these guidelines, especially with regard to humidity range, can result in a performance failure or damage to your floor and will void the warranty. In addition, it is important to maintain your floor in accordance with the flooring manufacturer's maintenance instructions.

These warranties do not cover damage or unsatisfactory performance caused by excessive moisture or moisture vapor including, but not limited to, improper humidity inside the home, excessive ground moisture that migrates into the home for any reason, excessive sub-floor moisture, water leaks caused by broken pipes or appliances, improper cleaning methods such as wet mopping or automated cleaning machines, weather conditions or natural disasters such as flooding or excessive rainfall.

Since wood is a natural product, it will tend to expand and contract as moisture and humidity levels inside the home may change. Accordingly, normal expansion and contraction which results in minor separations between flooring boards are not covered by these warranties.

The limited warranties do not cover color changes to any flooring which results from exposure to UV light. Normal exposure to sunlight will cause changes in the shading of any wood floor, and this is not considered a defect. Certain species including, but not limited to, American Cherry, Walnut, Brazilian Cherry, Tigerwood, and most Exotics, are especially susceptible to color change. Please contact your flooring retailer for more information. Area rugs should be moved occasionally, as they block sunlight and may give the appearance of discoloration under the rug.

The sole obligation and liability of the flooring manufacturer under our limited warranties is to repair, replace or refinish the floor at the flooring manufacturer's option. Only floors that were professionally installed will be eligible for labor cost reimbursement. If you installed the floor yourself, we will cover the cost of replacement materials only. (Any and all labor costs must be pre-approved by the flooring manufacturer Claims Department.)

These warranties **EXCLUDE** and will not pay consequential or incidental damages associated with any warranty claim. Flooring manufacturer will not pay costs associated with relocation during the repair process such as hotel, meals, or moving and storage of furniture. This limitation does not apply to claims for personal injury. Some states do not allow limits on warranties, or on remedies for breach in certain transactions. In such states, the limits in this paragraph may not apply.

Any flooring manufacturer product which is designated as "cabin grade", "tavern grade", "second", or "as is" is not covered by the above warranties.

THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF, OR AS OTHERWISE SET FORTH HEREIN. NO OTHER WARRANTIES, EXPRESSED OR IMPLIED, BY OPERATION OF LAW OR OTHERWISE ARE MADE, INCLUDING BUT NOT LIMITED TO, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. UNDER NO CIRCUMSTANCES SHALL FLOORING MANUFACTURER BE LIABLE FOR ANY LOSS OR DAMAGE ARISING FROM THE PURCHASE, USE, OR INABILITY TO USE THIS PRODUCT, FOR ANY SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, OR THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE. YOUR RIGHTS AND THE LIMITATIONS DESCRIBED ABOVE VARY FROM STATE TO STATE. THUS, IT IS IMPORTANT TO RETAIN THIS WARRANTY INFORMATION. NO INSTALLER, RETAILER, DISTRIBUTOR, AGENT, OR EMPLOYEE OF FLOORING MANUFACTURER HAS THE AUTHORITY TO INCREASE OR ALTER THE OBLIGATIONS OR LIMITATIONS OF THIS WARRANTY.

HANDLING OF CLAIMS UNDER THIS WARRANTY

Claims must be filed within the coverage period, and information verifying the date of purchase and pre-installation testing documentation are required. Flooring manufacturer reserves the right to have a designated flooring manufacturer representative inspect the floors and remove samples for technical analysis.

If you need to file a claim under this warranty, first contact your flooring manufacturer retailer within three months of experiencing a problem.

Any and all disputes arising out of the purchase of flooring manufacturer products or this warranty shall be subject to mandatory and binding arbitration in Johnson City, Tennessee, pursuant to the rules of the American Arbitration Association. Any trials by jury are expressly waived.

FLOORING FEATURES

PRODUCT	PAD & RECOAT	SAND & REFINISH *	INSTALL OVER RADIANT HEAT	WHERE TO INSTALL
SOLID	YES	YES	NO	ON GRADE ABOVE GRADE
ENGINEERED	YES*	YES	YES (OAK ONLY)	ON GRADE ABOVE GRADE BELOW GRADE

*If your floor is sanded down to the bare wood and a new finish is applied, all finish warranties must be assumed by the finish manufacturer.

*Engineered flooring with a veneer thickness of 2mm or less cannot be sanded and refinished, only a pad & recoat can be performed.

INSTALLATION INSTRUCTIONS

3/8" 7/16" 1/2" 9/16" 5/8"
10mm 11.1mm 12.7mm 14.2mm 15.8mm

Engineered Flooring Staple Down Installation

STAPLE/NAIL DOWN INSTRUCTIONS

ATTENTION

Inspect **ALL** materials carefully **BEFORE** installation. Warranties **DO NOT** cover materials with visible defects once they are installed. It is recommended that all engineered products acclimate for 2 days.

It is the responsibility of the installer/owner to determine if the job site subfloor and job site conditions are environmentally and structurally acceptable for wood floor installation. Flooring manufacturer declines any responsibility for wood floor failure resulting from or connected with subfloor, subsurface, job site damage or deficiencies after hardwood flooring has been installed.

STAPLE/NAIL DOWN INSTALLATION

Tools:

- 3/8" & 7/16" Staple Down using 1 1/4" to 1 1/2" long staples or 20 gauge cleats depending on the flooring product
- 1/2" & 5/8" Staple Down using 1 1/2" long staples or either 15 gauge or 18 gauge cleats depending on the flooring product

SUBFLOOR:

- **5/8" minimum thickness, preferred 3/4" or thicker plywood** installed with long edges at a right angle to the 16" on center floor joists and staggered so that the end joints in adjacent panels break over different joists. Nail at each bearing with 6d threaded or 8d common nails spaced 10" on center along intermediate joists.
- **1" x 4" to 6" wide, square edge, kiln dried coniferous lumber**, laid diagonally over 16" on center wooden joists. The ends of all boards are to be cut parallel to the center of the joists for solid bearing. Face nail each board solidly at every bearing on the joists with two nails (7d threaded or 8d common).
- **23/32" minimum O.S.B. on 19.2-inch minimum** center floor joists with system properly nailed or minimum 7/8" subfloor with 24" on center floor joists or trusses.
- Baseboards should be installed so that their lower edge is slightly above the level of the finished floor, but not nailed into the finished floor.
- Basement and crawl spaces must be dry and ventilated when plank or strip flooring is to be installed over them. In crawl spaces a vapor barrier should be provided. Black vapor barrier must be provided below subfloor on the ground. (6 mil. black)
- Subfloor should be flat or made to be flat to 3/16" in a 8' ft. radius.
- Particle board of any thickness is **NOT ALLOWED!**
- Adequate and proper nailing as well as soundness of the subfloor should be ascertained. Foreign material shall be removed from the subfloor surface and swept clean.
- The clean subfloor shall be covered wall to wall with one of the following: 15lb. asphalt saturated felt, moisture mat or Aquabar®B (no rosin paper). Butt the edges when positioning one or the above mentioned moisture retarder. Double the felt around heat ducts that may be in the floor.

Wood type subfloors should also be checked for moisture using a reliable moisture meter. Wood or plywood subfloors should not exceed 14% moisture content, the moisture content difference between hardwood flooring and subfloor should not exceed 4%. Check with your local distributor for your geographical variances.

General Staple/Nail Down Installation Instruction:

- Time at which to install hardwood flooring: Lay only after sheetrock and tile work are thoroughly dried and all but the final woodwork and trim have been completed. The building interior should have been dried and seasoned and a comfortable working temperature (at least 60° F) and a relative humidity of 35 – 55% should exist during installation.
- **DO NOT open until ready to install.**

Preparation of subfloor: Subfloor irregularities and undulation may cause any wood flooring installation to develop hollow spots between the flooring and subfloor and/or lead to noise, i.e. squeaking, popping or crackling. These hollow spots are NOT the result of any wood floor manufacturing defect and are NOT covered by the flooring manufacturer warranty.



- Adequate and proper stapling as well as soundness of the subfloor should be ascertained. Foreign material shall be removed from the subfloor surface and swept clean.
- The clean subfloor surface shall be covered, wall to wall, with 15 lb. asphalt saturated felt, Aquabar® B, or moisture mat (no rosin paper). Butt the edges of this felt when positioning it.
- Laying direction for plank flooring: Flooring should be laid at right angles to the floor joists and, if possible, in the direction of the longest dimension of the room.

Note: Normally, expansion space around the room should be the same distance as the thickness of the hardwood flooring.

- The floor should be installed from several cartons at the same time to ensure color and shade mix.
- End joints should never be closer than 4" to 6" from each other.
- Staple or Nail Engineered Plank Hardwood Flooring: The first and last row of flooring should be face nailed and filled, as well as staples placed at Tongue. Staple each board along the tongue every 4 to 6 inches apart and within 2 inches of each end joint. This should be done to the entire floor.

Notes:

- To avoid movement in hardwood floor relative humidity should be maintained year round at 35-55%
- The use of flooring putty to cover small cracks or face nail holes should be considered normal in hardwood flooring installation.



RADIANT HEAT (OAK ONLY) - See below.

Concrete or Plywood: Radiant Heat (Oak ONLY)

- Radiant Heat Subfloors on or above grade.
- The maximum temperature of subfloor under normal use should not exceed 80°F (Check with heat system manufacturer.)
- For correct water temperature inside heating pipes, check with manufacturer's suggested guidelines.
- Heating pipes must be covered with 1 1/4" of concrete or minimum of 1/8" below bottom side of plywood subfloor.
- Before installation of hardwood flooring, heat system must be operated at normal living temperature for a minimum of 14 days. One to two days before the flooring is laid, switch off heating unit. (At time of installation, subfloor should be 64°F to 68°F)
- Room temperature should not vary more than 15°F season to season. Flooring manufacturer approved systems must not exceed 8 watts per square foot heating.

FOR UNFINISHED PRODUCTS

- Do not start sanding product until adhesive has cured.

FLOATING INSTALLATION

- 3/8", 1/2", 9/16 or 5/8 product **3" width or wider** can be floated in some, not all, installations. If necessary call your supplier for details.

INSTALLATION INSTRUCTIONS

3/8" 7/16" 1/2" 9/16" 5/8"
10mm 11.1mm 12.7mm 14.2mm 15.8mm

Engineered Flooring Glue Down Installation

GLUE DOWN INSTRUCTIONS

ATTENTION

Inspect **ALL** materials carefully **BEFORE** installation. Warranties **DO NOT** cover materials with visible defects once they are installed. It is recommended that all engineered products acclimate for 2 days.

It is the responsibility of the installer/owner to determine if the job site Subfloor and job site conditions are environmentally and structurally acceptable for wood floor installation. Flooring manufacturer declines any responsibility for wood floor failure resulting from or connected with subfloor, subsurface, job site damage or deficiencies after hardwood flooring has been installed.

GLUE DOWN INSTALLATION

ADHESIVE: Using an appropriate, quality urethane adhesive is recommended.

TOOLS: The required tools for installation of these products include a hammer, hand power saw, chalk line, wood floor adhesive and recommended trowel.

Recommended Trowel: General 1/2" thick wood floor should use 3/16" wide 5/32" deep v-notch trowel to yield approximately 45 to 50 sq. ft. per gallon or 1/4" x 1/4" x 3/16" square notch. 5/16" thick wood flooring should use 3/16" x 1/4" x 1/2" contour v-notch to yield 60 sq. ft. per gallon. **Follow adhesive manufacturer's guidelines.**

General Installation Instruction:

Time at which to install hardwood flooring: Lay only after sheetrock and tile work are thoroughly dried and all but the final woodwork and trim have been completed. The building interior should have been dried and seasoned and comfortable working temperature (at least 60°F) should exist during installation.

Preparation of subfloor:

Subfloor irregularities and undulation may cause any wood flooring installation to develop hollow spots between the flooring and subfloor and/or lead to noise, i.e. squeaking, popping or crackling. These hollow spots are NOT the result of any wood floor manufacturing defect and are NOT covered by the flooring manufacturer warranty.

As part of your subfloor preparation remove any existing base, shoe mold or doorway thresholds. These items can be replaced after installation, but should be replaced in such a way as to allow at least 1/4" room for expansion around the perimeter of the room. All door casings should be notched out or undercut to allow for 1/4" room expansion and to avoid difficult scribe cuts. This is easily done by placing a piece of the engineered product on the subfloor as a height guide for your handsaw or jamb saw.

Note: Normal expansion space around the room should be the same distance as the thickness of the hardwood flooring.

Thoroughly clean subfloor:

Remove paint, wax, oil, plaster, "sheetrock mud" and other foreign materials, as well as obvious surface irregularities. #3-1/2 grit open coat paper may need to be used to grind a concrete subfloor. This will loosen any dirt, loose concrete or contaminants. Sweep or vacuum thoroughly. All previous or existing glues or adhesives must be removed before installing new hardwood floor. Concrete subfloors must be clean, flat, sound and sufficient compression strength (3000 lbs. P.S.I.) being sure that the surface is NOT slick.

Sections not flat due to waviness, trowel marks, etc. are to be flattened by grinding or the use of leveling compound. Especially along the walls, the subfloor flatness must be checked and if necessary improved. Flatten to 3/16" in 10' radius. In addition to cement subfloors, these wood flooring products can be installed over dry, flat subfloors such as plywood. No Particle board.

Time at which to install hardwood flooring: Lay only after sheetrock and tile work are thoroughly dried and all but the final woodwork and trim have been completed. The building interior should have been dried and seasoned and a comfortable working temperature (at least 60° F) and a relative humidity of 35 – 55% should exist during installation. If subfloor is concrete, check for dryness see below. If moisture is present, do not lay. All concrete subfloors on or below grade need to be tested.

Concrete subfloor Moisture Testing (minimum 3000 PSI):

Electrical Impedance Test and Electrical Resistance Test (Concrete Moisture Meters) Follow Moisture Meter MFG Guidelines. If Meter shows possibility of excess moisture further testing is required. Calcium Chloride Test. See below.

Relative Humidity Test (Standard test method for determining relative humidity on concrete floor slabs using Situ Probes. If test shows over 75% vapor retarder must be used or wait for further curing.

Calcium Chloride Test ASTM F-1869 Readings over 3 lbs and up to 7 lbs vapor retarder needed.

See NWFA installation guidelines chapter 3 Moisture Testing for full information of testing.


Check floor in several locations. Consult with your local flooring distributor for graphical variances.

Note: Normal expansion space around the room should be the same distance as the thickness of the hardwood flooring.

- The use of flooring putty to cover small cracks or face nail holes should be considered normal in hardwood flooring installation.

New wood type subfloors should also be checked for moisture using a moisture meter. In general, wood or plywood subfloors should not exceed 14% moisture content and no more than 4% MC difference between wood flooring and subfloor. Check with your local distributor for your geographical variances. If the plywood is used as an overlay over the existing subfloor, the thickness of the overlay material must be such as to yield a total 3/4" subfloor thickness.

Suggested Layout Working Line: EXAMPLE: For 3" Material, snap a chalk line 30 1/4" from the wall on the door side of the room. The small area will be your working space and the last to be installed. Temporarily nail straight board on chalk line.




Caution: Proper humidity must be controlled between 35 – 55% for successful performance before, during and after installation.

Installing the floor:

- The floor should be installed from several cartons at the same time to ensure color and shade mix.
- End joints should never be closer than 4 inches from each other.
- Install tongue into groove.
- Tongue and groove should be engaged by hand.
- Lift a plank periodically to check adhesive transfer.
- Remove nailed board and install remainder of flooring.
- Install base and mould after floor installation.
- Clean adhesive off surface of wood with cleaner and soft cloth. (see adhesive manufacturer's recommendations)

For Unfinished Products

- Do not start sanding product until adhesive has cured.



RADIANT HEAT (OAK ONLY) - See below.

Concrete or Plywood: Radiant Heat (Oak ONLY)

- Radiant Heat Subfloors on or above grade.
- The maximum temperature of subfloor under normal use should not exceed 80°F (Check with heat system manufacturer.)
- For correct water temperature inside heating pipes, check with manufacturer's suggested guidelines.
- Heating pipes must be covered with 1 1/4" of concrete or minimum of 1/8" below bottom side of plywood subfloor.
- Before installation of hardwood flooring, heat system must be operated at normal living temperature for a minimum of 14 days. One to two days before the flooring is laid, switch off heating unit. (At time of installation, subfloor should be 64°F to 68°F)
- Room temperature should not vary more than 15°F season to season. Flooring manufacturer approved systems must not exceed 8 watts per square foot heating.

IMPORTANT HEALTH NOTICE FOR MINNESOTA RESIDENTS:

SOME OF THE BUILDING MATERIALS USED IN THIS HOME (OR THESE BUILDING MATERIALS) EMIT FORMALDEHYDE. EYE, NOSE, AND THROAT IRRITATION, HEADACHE, NAUSEA AND A VARIETY OF ASTHMA-LIKE SYMPTOMS, INCLUDING SHORTNESS OF BREATH, HAVE BEEN REPORTED AS A RESULT OF FORMALDEHYDE EXPOSURE. ELDERLY PERSONS AND YOUNG CHILDREN, AS WELL AS ANY-ONE WITH A HISTORY OF ASTHMA, ALLERGIES, OR LUNG PROBLEMS, MAY BE AT GREATER RISK. RESEARCH IS CONTINUING ON THE POSSIBLE LONG-TERM EFFECTS OF EXPOSURE TO FORMALDEHYDE.

REDUCED VENTILATION MAY ALLOW FORMALDEHYDE AND OTHER CONTAMINANTS TO ACCUMULATE IN THE INDOOR AIR. HIGH INDOOR TEMPERATURES AND HUMIDITY RAISE FORMALDEHYDE LEVELS. WHEN A HOME IS TO BE LOCATED IN AREAS SUBJECT TO EXTREME SUMMER TEMPERATURES, AN AIR-CONDITIONING SYSTEM CAN BE USED TO CONTROL INDOOR TEMPERATURE LEVELS. OTHER MEANS OF CONTROLLED MECHANICAL VENTILATION CAN BE USED TO REDUCE LEVELS OF FORMALDEHYDE AND OTHER INDOOR AIR CONTAMINANTS.

IF YOU HAVE ANY QUESTIONS REGARDING THE HEALTH EFFECTS OF FORMALDEHYDE, CONSULT YOUR DOCTOR OR LOCAL HEALTH DEPARTMENT.

WARNING: Drilling, sawing, sanding or machining wood products can expose you to wood dust, a substance known to the State of California to cause cancer. Avoid inhaling wood dust or use a dust mask or other safeguards for personal protection. For more information go to www.P65Warnings.ca.gov/wood

COMPLIES WITH EPA TSCA Title VI and CARB ATCM PHASE 2 COMPLIANT for FORMALDEHYDE