






<p>1</p> 	<ol style="list-style-type: none"> 1. Make sure the subfloor is flat, structurally sound, level and is free of dust, solvent, paint, asphalt, sealers and other extraneous materials. 2. If installing over concrete, the concrete must be fully cured and permanently dry. It is the installer's responsibility to test the concrete for moisture. 3. If a moisture mitigation system is required, it must confirm to the ASTM F3010.
<p>2</p> 	<ol style="list-style-type: none"> 1. Assume the walls you are butting up against are not square. Using a chalk line, create a starting point for an edge of the material to follow. 2. Unroll the floorMuffler® Flex onto the floor in the opposite direction that you plan to install the flooring planks. Allow 2 hours to relax. Shaking the material once it is unrolled can help it to relax.
<p>3</p> 	<ol style="list-style-type: none"> 1. Roll out the next roll of floorMuffler® Flex in the same manner, making sure that the underlayment seams are butted together but not overlapping. 2. Trim as necessary to fit the surface area that needs to be covered.
<p>4</p> 	<ol style="list-style-type: none"> 1. If installing over concrete or below grade subfloors, be sure to tape the seams together with a moisture barrier seam tape.
<p>5</p> 	<ol style="list-style-type: none"> 1. Install the flooring per manufacturer's instructions.

For glue down installations, always follow the adhesive manufacturer's instructions. Make sure to use a floorMuffler approved adhesive. The list of approved adhesives can be found on each product page on the floorMuffler website.

